

OCAM

4X4
ACCESSORIES

INSTALLATION INSTRUCTIONS

PART NUMBER: BG-BYD-SHARK -6

APPLICATION: BYD SHARK 6

FITTING TIME: 30 minutes



OCAM 4x4 Accessories
31 Shirley Way, Epping, VIC 3076
Telephone (03) 9357-0306
Email: hello@ocam.com.au
ABN: 33166112278

IMPORTANT INFORMATION

- Always wear safety glasses and hearing protection.
- Make sure the work area is kept clean at all times.
- Check that all components, as listed, are present.
- Thoroughly read all instructions.
- This product or its fasteners must not be modified in any way.
- These instructions are accurate at the revision date and do not take into account any changes made by the vehicle manufacturer to vehicle design after the revision date, or other accessories that are or have been fitted to the vehicle.
- It is the responsibility of the installer to confirm correct operation and clearance of all components.
- All holes drilled must have all burrs and swarf removed then coated with a suitable rust preventative paint.
- Ensure that all hardware is fastened to torque specifications as detailed in the instructions.
- On completion of the job, these instructions are to be given to the customer.

PRODUCT CARE

- To maintain the appearance of the product, wash and dry regularly using a quality car wash.
- The product fixing should be periodically checked for correct torque.

Torque Settings		
BOLT SIZE mm	TORQUE Nm	TORQUE ft. lb
M5	5	4
M6	9	7
M8	22	16
M10	44	32
M12	77	57

Tools Required	

BOM		
Item	Quantity	Description
1	2	Abrasive Protection Tape
2	2	Small Round Plastic Washer
3	1	Large Round Plastic Washer
4	2	Plastic Bonnet Clip
5	1	Large Screw
6	2	Small Screw
7	2	Small White Screw Grommet
8	1	Large Black Screw Grommet



1. Raise bonnet and locate middle exposed hole of the bonnet. Fit supplied large screw grommet



2. Locate the elongated holes on the underside of the bonnet. Use the middle elongation as pictured and install 1 x small screw grommet. Repeat for the opposite side.



3. Fit the bonnet protector and fasten the middle tab with 1 x large screw. Then fasten the other 2 mounts with the small screws.



4. Fit hood mounting clip to bonnet protector. Align and install abrasive tape per to avoid paint being damaged by the clip. Repeat for the other side



5. Push hood mounting clip over the abrasive tape and the bonnet protector should be secure.



6. Cross check all mountings and then close the bonnet.