

OCCAM

4X4
ACCESSORIES

INSTALLATION INSTRUCTIONS



SKU: BG-D40

Vehicle Compatibility: Nissan Navara D40

Install Time: 0.25 hours

IMPORTANT INFORMATION

- Always wear safety glasses and hearing protection.
- Make sure the work area is kept clean at all times.
- Check that all components, as listed, are present.
- Thoroughly read all instructions.
- This product or its fasteners must not be modified in any way.
- These instructions are accurate at the revision date and do not take into account any changes made by the vehicle manufacturer to vehicle design after the revision date, or other accessories that are or have been fitted to the vehicle.
- It is the responsibility of the installer to confirm correct operation/clearance of all components.
- All holes drilled must have all burrs and swarf removed, then coated with a suitable rust preventative paint.
- Ensure that all hardware is fastened to torque specifications as detailed in the instructions.
- On completion of the job, these instructions are to be given to the customer.

PRODUCT CARE

- To maintain the appearance of the product, wash and dry regularly using a quality car wash.
- The product fixing should be periodically checked for correct torque.

Torque Settings		
BOLT SIZE (mm)	TORQUE (Nm)	TORQUE (ft. lb)
M5	7	5
M6	11.8	8.7
M8	28.8	21.3
M10	57.5	42.3
M12	99.8	73.7

Tools Required	
Phillips-head screwdriver	Trim removal tool

Item	Description	Qty
A	Bonnet protector	1
B	Screw insert	8
C	Washer	8
D	Screw	8

1. Raise and support the bonnet
2. Place the bonnet protector in position on the bonnet. Note/mark the clips that secure the rubber strip to the bonnet which align with the mounting holes in the bonnet protector.
3. Remove the clips noted/,arked in the previous step.



4. Fit the screw inserts into the holes in the bonnet that the clips were removed from.
5. Position the bonnet protector in place on the bonnet, with the bonnet protector mounting holes between the bonnet and the rubber strip.
6. Place the washers on the screws and screw into the screw inserts to secure the bonnet protector in place.