

OCAM

4X4
ACCESSORIES

INSTALLATION INSTRUCTIONS



SKU: BST2-RANGER-12

Vehicle Compatibility: Ford Ranger PX 1-3 2012-21,

Mazda BT50 2012-2020

Install Time: 30 minutes

IMPORTANT INFORMATION

- Always wear safety glasses and hearing protection.
- Make sure work area is kept clean at all times.
- Check that all components, as listed, are present.
- Thoroughly read all instructions.
- This product or its fasteners must not be modified in any way.
- These instructions are accurate at the revision date and do not take into account any changes made by the vehicle manufacturer to vehicle design after the revision date, or other accessories that are or have been fitted to the vehicle.
- It is the responsibility of the installer to confirm correct operation/clearance of all components.
- All holes drilled must have all burrs and swarf removed then coated with a suitable rust preventative paint.
- Ensure that all hardware is fastened to torque specifications as detailed in the instructions.
- On completion of the job, these instructions are to be given to the customer.

PRODUCT CARE

- To maintain the appearance of the product, wash and dry regularly using a quality car wash.
- The product fixing should be periodically checked for correct torque.

Torque Settings		
BOLT SIZE mm	TORQUE Nm	TORQUE ft. lb
M5	7	5
M6	11.8	8.7
M8	28.8	21.3
M10	57.5	42.3
M12	99.8	73.7

PARTS LIST



Left & right bonnet bracket 2



Ball stud bolts 4



Nut 4



Washer 4



Gas strut 2



1. Remove the factory nut from the bonnet
2. Install the front brackets to the bonnet using the factory bolts
3. Install the ball stud on the bracket with the nut and washer provided



4. Remove factory panel bolt from location shown.
5. Install the ball stud into the factory hole of the body by using the nut and washer provided.



6. Push the gas strut onto the ball joints, ensuring they are installed in the correct orientation as shown.
7. Repeat process on the other side.