

OCAM

4X4
ACCESSORIES

INSTALLATION INSTRUCTIONS



SKU: BST2-LC70-24

Vehicle Compatibility: LC70 78 79 Series 2024+

Install Time: 45 minutes

IMPORTANT INFORMATION

- Always wear safety glasses and hearing protection.
- Make sure work area is kept clean at all times.
- Check that all components, as listed, are present.
- Thoroughly read all instructions.
- This product or its fasteners must not be modified in any way.
- These instructions are accurate at the revision date and do not take into account any changes made by the vehicle manufacturer to vehicle design after the revision date, or other accessories that are or have been fitted to the vehicle.
- It is the responsibility of the installer to confirm correct operation/clearance of all components.
- All holes drilled must have all burrs and swarf removed then coated with a suitable rust preventative paint.
- Ensure that all hardware is fastened to torque specifications as detailed in the instructions.
- On completion of the job, these instructions are to be given to the customer.

PRODUCT CARE

- To maintain the appearance of the product, wash and dry regularly using a quality car wash.
- The product fixing should be periodically checked for correct torque.

Torque Settings		
BOLT SIZE mm	TORQUE Nm	TORQUE ft. lb
M5	7	5
M6	11.8	8.7
M8	28.8	21.3
M10	57.5	42.3
M12	99.8	73.7

PARTS LIST



Ball joints

2



Bonnet mounting brackets

2



Bolts

4



Clips

2



Gas struts

2



Washers

2



1. Remove bonnet hinge bolts, have a second person hold up bonnet while disconnected to prevent bonnet falling. Install bonnet mount bracket and secure using the supplied bolts.



2. Install the ball studs into the factory mounting holes, place a washer under each ball stud, and tighten securely.



3. Install gas strut by pushing sockets onto the ball joints. Ensure the gas struts are installed in the correct orientation as shown.
4. Check all bolts are tightened correctly.