

OCCAM

4X4
ACCESSORIES

INSTALLATION INSTRUCTIONS



SKU: BST2-LC70

Vehicle Compatibility: LC 75, 76, 78 79 Up to 2023

Install Time: 30 minutes

IMPORTANT INFORMATION

- Always wear safety glasses and hearing protection.
- Make sure work area is kept clean at all times.
- Check that all components, as listed, are present.
- Thoroughly read all instructions.
- This product or its fasteners must not be modified in any way.
- These instructions are accurate at the revision date and do not take into account any changes made by the vehicle manufacturer to vehicle design after the revision date, or other accessories that are or have been fitted to the vehicle.
- It is the responsibility of the installer to confirm correct operation/clearance of all components.
- All holes drilled must have all burrs and swarf removed then coated with a suitable rust preventative paint.
- Ensure that all hardware is fastened to torque specifications as detailed in the instructions.
- On completion of the job, these instructions are to be given to the customer.

PRODUCT CARE

- To maintain the appearance of the product, wash and dry regularly using a quality car wash.
- The product fixing should be periodically checked for correct torque.

Torque Settings		
BOLT SIZE mm	TORQUE Nm	TORQUE ft. lb
M5	7	5
M6	11.8	8.7
M8	28.8	21.3
M10	57.5	42.3
M12	99.8	73.7

PARTS LIST



LH bonnet mounting bracket 1

RH bonnet mounting bracket 1



Washer 6

Bolt 4

Ball stud 2



Gas strut 2



1. Remove rear bonnet hinge bolt, install bonnet mount bracket using supplied bolt and washer. Tighten bolt just enough so the bracket can still move.



2. Remove front bolt, swing bracket to align front bolt hole and secure with supplied bolt and washer. Tighten bolts fully.



3. Remove factory panel bolt and install supplied ball stud.
4. Install gas strut by pushing sockets onto ball joints. Ensure gas strut is installed in correct orientation as shown.
5. Check all bolts are tightened correctly.