

# O CAM

**4X4**  
**ACCESSORIES**

## INSTALLATION INSTRUCTIONS



**SKU: BST2-MT-19**

**Vehicle Compatibility: Triton MR, 11/2018-23**

**Install Time: 30 minutes**

## **IMPORTANT INFORMATION**

- Always wear safety glasses and hearing protection.
- Make sure work area is kept clean at all times.
- Check that all components, as listed, are present.
- Thoroughly read all instructions.
- This product or its fasteners must not be modified in any way.
- These instructions are accurate at the revision date and do not take into account any changes made by the vehicle manufacturer to vehicle design after the revision date, or other accessories that are or have been fitted to the vehicle.
- It is the responsibility of the installer to confirm correct operation/clearance of all components.
- All holes drilled must have all burrs and swarf removed then coated with a suitable rust preventative paint.
- Ensure that all hardware is fastened to torque specifications as detailed in the instructions.
- On completion of the job, these instructions are to be given to the customer.

## **PRODUCT CARE**

- To maintain the appearance of the product, wash and dry regularly using a quality car wash.
- The product fixing should be periodically checked for correct torque.

<b>Torque Settings</b>		
<b>BOLT SIZE mm</b>	<b>TORQUE Nm</b>	<b>TORQUE ft. lb</b>
<b>M5</b>	<b>7</b>	<b>5</b>
<b>M6</b>	<b>11.8</b>	<b>8.7</b>
<b>M8</b>	<b>28.8</b>	<b>21.3</b>
<b>M10</b>	<b>57.5</b>	<b>42.3</b>
<b>M12</b>	<b>99.8</b>	<b>73.7</b>

# PARTS LIST



LH bonnet mount braket 1



LH bonnet mount braket 1



LH bottom mount bracket 1



RH bottom mount bracket 1



Gas struts 2



1. Remove forward bonnet hinge bolt. Install bonnet mount bracket and secure with factory bolt.



2. Remove headlight mount bolt and panel bolt. Install lower mount bracket and secure using the factory bolts.



3. Install the gas struts by pushing sockets onto the ball joints. Ensure gas struts are installed in correct orientation as shown.