

OCCAM

4X4
ACCESSORIES

INSTALLATION INSTRUCTIONS



SKU: BST2-NP300

Vehicle Compatibility: NP300, 2015-Current

Install Time: 30 minutes

IMPORTANT INFORMATION

- Always wear safety glasses and hearing protection.
- Make sure work area is kept clean at all times.
- Check that all components, as listed, are present.
- Thoroughly read all instructions.
- This product or its fasteners must not be modified in any way.
- These instructions are accurate at the revision date and do not take into account any changes made by the vehicle manufacturer to vehicle design after the revision date, or other accessories that are or have been fitted to the vehicle.
- It is the responsibility of the installer to confirm correct operation/clearance of all components.
- All holes drilled must have all burrs and swarf removed then coated with a suitable rust preventative paint.
- Ensure that all hardware is fastened to torque specifications as detailed in the instructions.
- On completion of the job, these instructions are to be given to the customer.

PRODUCT CARE

- To maintain the appearance of the product, wash and dry regularly using a quality car wash.
- The product fixing should be periodically checked for correct torque.

Torque Settings		
BOLT SIZE mm	TORQUE Nm	TORQUE ft. lb
M5	7	5
M6	11.8	8.7
M8	28.8	21.3
M10	57.5	42.3
M12	99.8	73.7

Tools Required	
socket wrench	screwdriver

PARTS LIST



Gas strut

2



Bonnet mount bracket

2



Nut

4



1. Remove the factory nut from the bonnet.
2. Install the bonnet mounting brackets with the factory nut.
3. Install the ball stud at the upper end of the strut on the bracket with the nut provided.



4. Install the ball stud at the lower end of the strut into the factory threaded hole of the body as shown.

Note: some older models may not be equipped with factory threaded holes, two additional locknuts are provided for locking the ball studs



5. Repeat process on both sides.

Ensure gas struts are installed in correct orientation as shown.