

OCCAM

4X4
ACCESSORIES

INSTALLATION INSTRUCTIONS



SKU: BST2-MT-18

Vehicle Compatibility: Mitsubishi Triton MQ 05/2015-11/2018,

Mitsubishi Pajero Sport 2015-2019

Install Time: 30minutes

IMPORTANT INFORMATION

- Always wear safety glasses and hearing protection.
- Make sure work area is kept clean at all times.
- Check that all components, as listed, are present.
- Thoroughly read all instructions.
- This product or its fasteners must not be modified in any way.
- These instructions are accurate at the revision date and do not take into account any changes made by the vehicle manufacturer to vehicle design after the revision date, or other accessories that are or have been fitted to the vehicle.
- It is the responsibility of the installer to confirm correct operation/clearance of all components.
- All holes drilled must have all burrs and swarf removed then coated with a suitable rust preventative paint.
- Ensure that all hardware is fastened to torque specifications as detailed in the instructions.
- On completion of the job, these instructions are to be given to the customer.

PRODUCT CARE

- To maintain the appearance of the product, wash and dry regularly using a quality car wash.
- The product fixing should be periodically checked for correct torque.

Torque Settings		
BOLT SIZE mm	TORQUE Nm	TORQUE ft. lb
M5	7	5
M6	11.8	8.7
M8	28.8	21.3
M10	57.5	42.3
M12	99.8	73.7

Parts list		
Gas struts x2	Bonnet mounting bracket x2	Ball joint bolt x4
Nut x4	Washer x4	



1. Remove forward bonnet hinge bolt. Install bonnet mount bracket with the slotted side aligned with bonnet hinge bolt hole. Secure with the factory bolt and tighten.
2. Install ball stud to bonnet mount bracket, secure with supplied nut and washer.



3. Install the ball stud bolt to the vehicle body with supplied nut and washer.



4. Install gas strut by pushing sockets onto the ball joints. Ensure gas struts are installed in correct orientation as shown.
5. Perform a final check ensuring all bolts are tightened.