

Tailgate lock kit suit Ford Ranger - 2011-2022

PX PX2 PX3

Mazda BT-50 2012-2020

Install guide



1.Remove cover for tailgate cover

2.Install Mechanism as per pictured



3. Fit wiring along chassis Channel avoid any rotating parts or exhaust



Fit through the engine firewall grommet on drivers side

4. Wire green wire and blue wire to factory wiring on the connector as per picture in drivers side footwell panel



Central Locking (LOCK)	Yellow	Grey/Brown
Central Locking (UNLOCK)	Grey	Violet/Green (thick wire)

WARNING: Be aware there may be both THICK (3.0mm) and THIN (1.5mm) Violet/Green wires. The THICK wire is correct. Please use a test light to confirm before connecting.

5. Test the tailgate locks correctly

6. Put all trimming and covers back together