

FITTING INSTRUCTIONS

79 SERIES DUAL CAB T-SHAPED CENTRE ROOF CONSOLE

Introduction. This console can be fitted to the vehicle without drilling any holes. It is fitted by utilising the sun visor mounting screws, the grab handle captive nuts, and the interior light captive nuts.

Step 1. Remove the console fitting kit from inside the console.

Step 2. Unscrew one side of each sunvisor - the side closest to the rear view mirror.

Step 3. Remove the front threaded screw that holds the passenger's side grab handle onto the vehicle. Remove the front Christmas tree plug that covers the front captive nut for a driver's side grab handle. Remove the interior light.

Step 4. Without attaching the sunvisor feet. Place the console in position and replace the sunvisor screws back into the vehicle to bend the consoles front mounting brackets into the correct shape.

Before fitting the console take note of the positions of the sunvisor's foot locating pin hole and screw hole. Be careful not to fit the screw into the locating pin hole.

Step 5. Remove the sunvisor screws and the console.

Step 6. Install the wiring for the radio(s) or accessories.

Step 7. Install your radio(s) or accessories into the console - see "instructions for fitting a radio or accessories into the console".

Step 8. Prepare the roof console to accept the genuine interior light. Place the interior light on the base of the console, covering the hole. Ensure that the interior light is sitting flush on the console and in the centre of the console. Using the two 20mm, 6 gauge self tapping screws supplied with the "console fitting kit", screw the interior light onto the console. Do not attempt to drill any holes through the upholstery, the self tapping screws do not need a hole to screw into the console base. **Make sure the screws are not too close to the edges of the plywood hole.** Remove the interior light from the console to allow access to the consoles rear mounting screw holes. It is now a simple procedure to re-mount the interior light after the console is fitted.

Step 9. Make sure the interior light wire is long enough to reach past the base of the console. A gentle pull will free up some extra length of this wire. In most cases it will be necessary to extend this wire.

Step 10. Place the console in position, make sure the interior light wiring is laced through the 25mm diameter hole in the timber spacer at the back of the console. Secure the console on the driver's side by fitting the threaded screw with the snap cap washer. Secure the console on the passenger's side by re-attaching the grab handle using the remaining 25mm x 6mm threaded screw in the fitting kit. Next, re-attach the sunvisors. Then using the two 50mm x 4mm threaded screws and washers in the fitting kit attach the back of the console to the interior light captive nuts. The interior light earth wire supplied with the "console fitting kit" should be attached between the washer and the head of one of these two mounting screws.

Step 11. Connect the interior light wiring plug, then run the earth wire through the hole in the interior light. Re-mount the interior light onto the base console and use one of the mounting screws to connect the earth wire to the earth contact point on the interior light. Position the earth wire so it won't be affected by the heat generated from the interior light globe.

Step 12. Place the snap cap over the head of the threaded screw above the driver's side door.