


# Fitting Instructions

Description :	OCAM Heavy Duty Steel Side Steps
Model :	To suit Toyota Prado 150 Series 2009+
Item NO. :	SS2-150



## Before Installation

- Please read the instruction carefully. They will also help you to avoid scratches or other potential damage to your vehicle.
- All images are for reference only and may vary slightly with the actual product you've received.

## Care and Cleaning







- Mild soap may be used also to clean the side steps.
- Please periodically check and retighten all the hardware and keep your investment clean for a fresh look.

# Fitting Instructions

Standard locking torque

M10 - 80 Nm | M12 - 90 Nm

## PARTS LIST




Item	Item NO.	Description	Qty	Item	Item NO.	Description	Qty
o1	200305166	 Main step LHS	1	o2	200305167	 Main step RHS	1
o3	TY001512	 T-bolt M8	13	o4	200357583	 T-bolt M8 with wire	1
o5	200193010	 M8 plastic clip	12	o6	200006015	 Coil spring line M8	2

## Hardware kit


Item	Item NO.	Description	Qty
o7	3000160	Spring washer M8	13
o8	3000171	M8 hex nut	13
o9	3000245	Flat washer M8x24x2mm	13
o10	3000333	8-1.25mm x 25mm Combo Bolt	4

# Fitting Instructions


## Fitting Instructions



1. **Main Step RHS installation:** Place the 03 T-bolt M8 inside the hole for the weld mount & use 05 M10 plastic clip to hold the T-bolt M8 in place. Fasten the T-bolt with 08 M8 hex nut on plate 07 Spring washer M8 09 Flat washer M8x24x2mm. If the chassis has a captive nut in position, please directly use 010 8-1.25mm x 25mm Combo Bolt as an alternative.



# Fitting Instructions



2. **Main Step LHS installation:** Place the  $\varnothing 3$  T-bolt M8 inside the flank for the weld mount & use the  $\varnothing 5$  M10 plastic clip to hold the T-bolt M8 in place. Fasten the T-bolt with  $\varnothing 8$  M8 hex nut on plate  $\varnothing 7$  Spring washer M8  $\varnothing 9$  Flat washer M8x24x2mm. If the chassis has a captive nut in place, please directly use  $\varnothing 10$  8-1.25mm x 25mm Combo Bolt as an alternative.

Please remove the OE skip plate prior to installing the rear chassis mount bracket. When the rear chassis mount bracket is installed, please re-install the OE skip plate.

3. Adjust the steps to the correct position and then fasten all bolts & nuts.